


## wedi® Subliner Dry

Installation on Floors or other suitable, non-waterproof underlayments or substrates



1. Lay out wedi® Subliner Dry and cut to size using a knife or scissors.
2. Apply thin-set mortar to the prepared subfloor using a 1/8 in. × 1/8 in. or 1/4 in. × 1/4 in. notch trowel.
3. Insert wedi® Subliner Dry with the printed side facing upward and press on with a rubber grout float. Remove air pockets and other foreign particles from below the sheets.
4. The sheets must overlap 2 in. at joints and transitions. Leave these overlapping areas free of any thin-set and use tape to keep them folded upward and clean. Once the thinset has cured, apply wedi® Sealant 620 as a full bed onto the lower mats seam connection area and press the top overlap flat into the wedi® Sealant 620. If you cannot clearly see the wedi® 620 Sealant spread past the Subliner Dry overlap, a second bead should be applied on the seam, flattened to a minimum of 1 in. past each side of the seam.



5. Spread the wedi® Sealant 620 flat using a putty knife. Cross joints should be avoided.
6. In complete wet rooms, wedi recommends to flash Subliner Dry up the wall by 2 in. (50.8 mm) where it is still invisible behind baseboard tile or wood applications.
7. Start setting tile once wedi® 620 Sealant has been allowed to cure for 24 hours. Exposure to water is possible after 48 hours providing that the wedi® 620 Sealant is dry to the touch. wedi® 620 Sealant is moisture curing and may require extended cure times in dry and cold climate or when installed below epoxy setting materials or larger format, dense tiles.

